

002260" 91E89960




Fig. 1

002260" STE316




Fig. 2

002260" 97E3950




Fig. 3

402

404

406

Module ID	Pointer	Function
▪ ▪ ▪	▪ ▪ ▪	▪ ▪ ▪

408

400

Fig. 4a

Executive Module 320 ID	TMIF 332a Pointer	fQuitUsing
Executive Module 320 ID	TMIF 332b Pointer	fQuitUsing
Executive Module 320 ID	TMIF 332c Pointer	fQuitUsing
Test Module 330a ID	TMIF 332c Pointer	fQuitUsing
Test Module 330b ID	TMIF 332c Pointer	fQuitUsing

422

424

426

428

430

400

Fig. 4b

Executive Module 320 ID	TMIF 332a Pointer	fQuitUsing	422
Executive Module 320 ID	TMIF 332b Pointer	fQuitUsing	424
Executive Module 320 ID	TMIF 332c Pointer	fQuitUsing	426
Test Module 330a ID	TMIF 332c Pointer	fQuitUsing	428
Test Module 330b ID	TMIF 332c Pointer	fQuitUsing	430

400 ↗


Fig. 4c


Executive Module 320 ID	TMIF 332a Pointer	fQuitUsing	422
Executive Module 320 ID	TMIF 332b Pointer	fQuitUsing	424


400 ↗

Fig. 4d

002260 " 092200

**Fig. 5a**

**Fig. 5b**

**Fig. 5c**

002260" STE9960




Fig. 6